E**V?**HEAT.,

SERIES 20 INSTALLATION QUICK GUIDE



1



HOSE:

5/8" standard 3/4" (optional)



PORT FITTINGS:

3/8" minimum 5/8" standard 3/4" (optional)



ISOLATION VALVES:

Full-flow recommended for service

ORIENTATION: Point outlet port directly upward.



VIBRATION: Must be


isolated from engine vibration.

MOUNTING BRACKET INSTALL OPTIONS:





၁




RETURN:

- High
- Toward Rear
 - Away from Engine T-stat

SUPPLY:

- LowToward Front
- Away from Return Port

4



System Fault Indicator